



# Chime 2



## Get Alerts in Any Room.

With Arlo Chime 2, receive instant alerts for a doorbell press or when motion or audio is detected by your Arlo doorbell or camera. Easily plug into a wall outlet and connect directly to Wi-Fi for a wire-free install. Deter unwanted guests by triggering the built-in siren and select from a variety of melodies.



**Receive instant audible notifications for a doorbell press or motion alert.**



**Free of power cords and wiring hassles.**



**Connects Directly to Wi-Fi.**



**Deter unwanted guests with a built-in siren.**



**Select from a variety of melodies to customize**

### Compatibility

- All Arlo Video Doorbells and Audio Doorbells
- All Arlo Cameras (excluding Arlo Go)
- Arlo Pro 3 Floodlight Camera

### Requirements

- High-speed Internet connection with 2.4GHz Wi-fi
- AC Adapter Input: 100-240V AC, 50/60Hz

### Certifications

- FCC, IC, CE

### Dimensions & Weight

- Dimensions: 3.6 x 1.22 x 1.76 in (92 x 31 x 44.8 mm)
- Weight: 85 g. / 3 oz.

### What's Inside

- (1) Chime 2
- (1) Quick Start Guide

### Specifications

- Networking: 802.11 b/g/n
- Audio: Speaker
  - Variety of melodies and presence simulation
- Frequency: 2.4GHz
- Indoor Use Only
  - Operating temperature: 32° F to 113° F (0° C to 45° C)

### Warranty

- [www.arlo.com/warranty](http://www.arlo.com/warranty)

This product comes with a limited warranty that is valid only if purchased from an Arlo authorized reseller.

©2021 Arlo Technologies, Inc. Arlo, Arlo logo, and Every Angle Covered are trademarks of Arlo Technologies, Inc. Any other trademarks herein are for reference purposes only.